



## H201 - Handheld Fiber Optic Temperature Monitor



- Rugged, Compact Design for quick temperature reading and testing
- 2 to 8 Channels, Expandable
- Easy to use, USB powered, Plug and Play
- Suitable for HV applications and best in class EMI, ESD Immunity
- Built-in display with Remote Client software for advance visualizations

**Rugged design, designed for reliability, handheld fiber optic temperature monitor for Factory Testing, Industrial and Laboratory applications.**

## Product Summary

The Rugged Monitoring H201 is a compact design, designed for reliability to operate in extreme EMI, RFI, Microwave and High Voltage environments. The H201 Fiber optic monitor combines reliability and user friendly interface in the monitor and software. It is a multi-channel fiber optic temperature monitor with precision measurement for Factory Testing, Industrial and Laboratory applications. The H201 has a measuring range from -271 °C to +300 °C. The system is based on proven GaAs technology and designed for Plug and Play operation. Its immunity to extreme test conditions and harsh environment makes H201 the default choice for temperature testing and measurement.

The H201 is designed to connect to the fiber optic temperature sensors (GaAs technology based) and provide temperature readings on local display. Plug and Play functionality provides the flexibility to interchange sensors without the inconvenience/concerns of calibration. The measured temperature data can also be sent to third party datalogger / system through serial communication like RS-485 or analog outputs like 0-10 V / 4-20 mA. The H201 monitor comes with Rugged Connect software which is designed for remote visualization of data, perform analysis and integrate with other Test and Monitoring platforms. Rugged Connect software is capable of collecting data from 6 x H201 or other rugged monitoring systems simultaneously. Industry standard drivers available for a quick and easy connect to most popular laboratories software / computing environments. There is a dedicated team of experts available for customizing fiber optic temperature solutions to meet specific customer needs.

# Applications

- Transformer factory: Hottest spot testing
- Medical Equipment testing (MRI, PETSCAN, NMR)
- Commercial Grade Microwave heating applications
- Industrial process control and monitoring applications
- Chemical and process Industries
- Food and Beverage Processes
- Wood drying industry
- Electric Vehicle and Battery Testing

## Benefits

- Sensors do not require any recalibration
- No shift over time, high stability and repeatability
- Handheld system with Robust packaging
- Each Monitor comes with a complete NIST calibration certificate
- Software designed for integration into test platforms
- Robust datalogging and Analytics
- Customizable according to customer specific applications
- Suitable for OEM-type applications


## TECHNICAL SPECIFICATIONS

|  |   |
|--|---|
| Measurement Range                                      | -80 °C to +300 °C   |
| Measurement range ( <i>Optional Range extensions</i> ) | Down to 4 °K / Up to +300 °C                                  |
| Resolution   | 0.1 °C  |
| Accuracy   | ±1.0 °C (+/- 0.2 °C in relative temperature)                  |
| Number of Channels                                     | 2 - 8 Channels  |
| Scan rate  | 200 ms / channel  |
| Logging  | 1 sec interval on USB   |
| Config port  | USB (to use with Rugged connect windows software)             |
| Serial port  | RS-485 (RS-232 optional converter) with Modbus                |
| Power  | 5 Volts USB powered   |
| Battery  | Optional Battery Module available                             |
| Memory   | MicroSD external memory slot (up to 2 TB)                     |
| Analog output module                                   | Fully configurable 0-10 V / 4-20 mA optional module available |
| Dimensions   | 12.5 cm x 18 cm x 6.9 cm                                      |
| Weight   | 0.64 Kg. (for 8 channel unit)                                 |
| operating temp   | -30°C / 55°C  |
| Storage temp   | -30°C / 65°C  |
| Humidity   | 95% Non Condensing  |

## ORDERING CODE



H201 = Lab Instrument, 201 Series



Number of Channels,  
Ex: 08 = 8 Channels (Available 02, 04, 06, 08)



### Rugged Monitoring Services

Rugged Monitoring provides customization of sensors, monitors & software. In addition we offer on-site commissioning services, maintenance contracts and technical support to all customers worldwide.



### About Rugged Monitoring

Industry leading team of fiber optic experts with 100+ years of combined experience committed to delivering customizable solutions for challenging applications. We offer a range of reliable, high performance, customizable sensors and monitoring solutions that are immune to external influence.

2018 Rugged Monitoring Company. All rights reserved. Information subject to change without notice. All trademarks are properties of their respective companies, as noted herein.

+1-418-767-0111

info@ruggedmonitoring.com

www.ruggedmonitoring.com

DS0022R02\_H201\_EN\_81